P510E IP IPTV set-top box Instructions for use



Important: Read carefully before use and retain for future reference.





Table of contents

1	Safet	y information	3
	1.1	Signs and symbols used	3
	1.2	General safety information	3
2	Inten	ded use	5
3	Scop	e of delivery	5
4	Conn	ections	6
5	Gettir	ng started	6
	5.1	Inserting the batteries into the remote control	7
	5.2	Cable connections	7
	5.3	Pairing the remote control with the set-top box	8
	5.4	Choosing the menu language	8
	5.5	Establishing the network connection	9
	5.6	Software updates	13
6	Remo	te control	13
	6.1	Button functions	14
	6.2	Changing the operating mode	16
	6.3	Programming the TV set	16
	6.4	Controlling the TV	19
	6.5	Unpairing the remote control (Bluetooth mode)	20
	6.6	Resetting the remote control	20
7	Clean	ing	21
8	Retur	ning used devices	21
9	Trout	pleshooting	22
10	Legal	notes	25
	10.1	Registered trademarks and notes on licences	25
	10.2	Open Source Software	25
11	Decla	ration of conformity	25
12	Tech	nical specifications	26

1 Safety information

Please read the following information carefully before you start using the product. This helps prevent misuse and resulting personal injury, faults and/or damage to the hardware and software.

Save these instructions for use in case of future questions and pass them on to future users.

1.1 Signs and symbols used

Please make yourself familiar with the signs and symbols used in this instructions for use.

Indicates a potential risk. If not avoided, it can result in serious injury or death.

ATTENTION

Indicates a potentially damaging situation. If not avoided, the component or an object in its vicinity may be damaged.



Additional information

1.2 General safety information

- → The devices are for indoor use only.
- → Only operate the set-top box with the power supply unit and connecting cables included in the package contents.
- → Regularly check the cable of the power supply unit for damage. In case of damage, disconnect the power supply unit from the mains network and contact your provider.
- → Always replace damaged cables with equivalent cables.
- → Only connect the power supply unit of the set-top box to the specified mains voltage.
- → The set-top box has to be connected to an outlet that is easily accessible. You must be able to disconnect the set-top box from the mains network at any time.
- → Maintain the following minimum clearances around the set-top box: 10 cm above, 5 cm behind, 2 cm on the sides.
- → Never put the set-top box into a cabinet or shelf with insufficient ventilation.

- ➔ Do not let the devices fall on the floor. Do not install the set-top box more than 2 metres above the floor.
- ➔ Do not try to repair the set-top box yourself. Doing so could put electrical safety at risk. If the set-top box was dropped or if water got into the unit, disconnect the set-top box from the mains network immediately and contact your provider.
- → Protect the devices against moisture and dripping or splashing water.
- ➔ Do not place objects filled with liquids, such as a vase, on top of the set-top box.
- \Rightarrow Only operate the devices in a dry, dust-free environment.
- ➔ Protect the devices and the batteries of the remote control against direct sunlight, open flames and other heat sources, such as radiators.
- → Do not place objects such as other devices or candles on top of the set-top box.
- ➔ In case of an extended absence and during thunder storms, disconnect the power supply unit of the set-top box from the mains network.
- → Also disconnect all devices connected to the set-top box.
- ➔ Do not use hard or sharp objects such as fingernails or knives when operating the remote control.
- → The batteries included in the package contents are not rechargeable.
- → Take the batteries out of the remote control if you will not be using it for an extended period of time.
- ➔ If the remote control is defective, remove the batteries and contact Customer Service.
- → Keep the devices out of reach of children.

(i) Heating of the set-top box

- The heating of the set-top box is in the permissible range. However, sensitive furniture finishes may become discoloured over time due to ongoing heat exposure.
- ➔ The base can cause discolouration of furniture finishes. Place the settop box on a suitable underlay if needed.

2 Intended use

The set-top box is intended to receive TV and radio signals in conjunction with IPTV systems. The remote control is intended for operating the set-top box and TV sets. Any other use constitutes improper use. The manufacturer assumes no liability for errors, faults or damage caused by improper use. This includes the following in particular:

- Improper connection and operation
- Use of unsuitable data media or accessories
- Failure to comply with the installation and storage conditions
- Infection of software components with computer viruses
- Modification of the hardware and software

3 Scope of delivery

- Set-top box
- Power supply
- High speed HDMI® Cable (1,5 m)
- Network cable (3 m)

- Remote control
- 2 x alkaline batteries type AAA
- Instructions for use

4 Connections



- ¹⁾ Depending on the configuration of the IPTV system, the set-top box and the operating mode of the remote control.
- ²⁾ For service use only, or as instructed by your provider. The connection of media can influence the serviceability of the set-top box.

5 Getting started



Danger due to electrical voltage and resulting fire hazard

➔ The cables must not be kinked or trapped.

ATTENTION

Risk of malfunctions or defects of the device

Incorrect installation

 Connect the cables to the set-top box in the correct order. Make sure that the network cable engages audibly.

Interrupting the power supply during installation

→ Never disconnect the power to the set-top box box during installation or when updating the software. This avoids possible damage. The set-top box requires an active internet connection to connect with an IPTV system. Use either a network cable or WiFi to establish the connection. Please note, however, that if you connect to WiFi and other devices simultaneously use this internet connection, the bandwidth may be limited. This can cause issues with playback or interruptions.

5.1 Inserting the batteries into the remote control

- Insert the batteries into the remote control (see Figure 2 on page 7). To do so, press down the battery cover at the mark and slide it back ①, to open the battery compartment.
- 2. Place the batteries in the battery compartment **2**, making sure the polarity is correct (see markings on the bottom of the battery compartment).
- 3. Insert the lug of the cover into the opening 3 on the battery compartment and push the battery compartment cover forward 4 until it audibly latches into place.



Figure 2: Inserting the batteries

5.2 Cable connections

1. Connect the set-top box as shown in Figure 3 on page 8. Observe the correct connection sequence:

1 HDMI[®] cable

Network cable

- 3 Power supply
- 2. Turn on your TV set.





5.3 Pairing the remote control with the set-top box

When the set-top box is used for the first time, the remote control is automatically detected.

- 1. Wait until a remote control symbol is displayed on the TV set.
- 2. Press the button **OK** to start the automatic detection.
- 3. The remote control is now paired with the set-top box. Pairing can take a few minutes.

5.4 Choosing the menu language

After the remote control is paired with the set-top box, the language selection options are displayed. Select the language of your choice for the user interface.

- 1. Select the language you want.
- 2. Confirm your selection by pressing the **OK** button.

Langaago		
 English 		
 Deutsch 		
 Français 		
 Italiano 		
 Português 		
 Lëtzebuergesch 		

Figure 4: Language selection

5.5 Establishing the network connection

If you have already established the network connection with a network cable and want to switch to WiFi, disconnect the network cable and power supply unit. Reconnect the power supply unit to the set-top box after about 5 seconds to open the setup menu.

If you have established the network connection with a network cable, you are forwarded automatically. To establish the network connection with WiFi, continue reading in Section "Establishing a WiFi connection" on page 9.

5.5.1 Establishing a WiFi connection

Various methods are available for establishing a WiFi connection:

- Search: The set-top box searches for available WiFi networks.
- Advanced: Use WPS, or enter the SSID manually.

5.5.1.1 WiFi search

- 1. In the setup menu, select the menu item **Connecting to WiFi**.
- 2. Activate the button **Search** by pressing **OK** (see Figure 5 on page 10).
- 3. Select the WiFi network you want to use from the list that is displayed. Make sure the signal strength is adequate (see Figure 6 on page 11).
- 4. Use the on-screen keyboard that is displayed to enter the WiFi password and confirm your input by pressing **OK**.
- 5. Wait until the connection is established and then press **Quit** repeatedly until the message **Successfully established the network connection.** is displayed.

Connecting to WiFi	Quit
Start the search for available networks or select advanced m establishing the WiFi connection.	ethods for
Search Advanced	

Figure 5: WiFi setup

Connecting to WiFi	Back	Quit
Select the desired	network.	
• WLAN_1		6 GHz 🔒 💵
NATHALIE34		2,4 GHz 🔒 💵
 WLANSpeed10 		5 GHz 🔒 💵
Zuhause10.0		5 GHz 🔒 💵
• WLAN_		5 GHz 🔒 💵
Search aga	in	



5.5.1.2 Advanced WiFi setup

(i) Not all of the methods described here may be compatible with your router.

You can select from various methods in the advanced WiFi setup.

- **WPS button:** The connection is established automatically after you press the WPS button on your router.
- **WPS PIN:** The connection has to be enabled by entering the PIN on the router web page.
- **SSID:** Manually enter the network name.
- Search: Search for available networks (see Section "WiFi search" on page 10).

To establish a WiFi connection using the advanced WiFi setup, proceed as follows:

- 1. In the setup menu, activate the button Advanced.
- 2. Navigate to the setup method of your choice.
- 3. Then follow the instructions on the TV set.

Connecting to WiFi		Back	Quit
Select the method for estab	olishing th	e WiFi connectio	n.
WPS button	To connec	t, press the WPS butto	n on your router.
PIN code			
Enter SSID			
 Search 			

Figure 7: Advanced WiFi setup

5.5.2 Checking the WiFi status

In the **WiFi status:** menu, you can access the current data for your WiFi connection such as the signal strength or the MAC address of your WiFi adapter.

WiFi status			Quit
	Connection state:	Connected	
	Signal strength:	-27 dBm	
	Data transmission rate:	144.0 MBit/s	
	IP:	172.16.62.14	
	SSID:	OCI-DEV-STB-2.4	
	Encryption:	WPA2	
	Frequency:	2447	
	WAP MAC:	ba:69:f4:f5:18:5a	
	WiFi MAC:	20:50:e7:42:4f:2c	
	Refres	sh	

Figure 8: WiFi status overview

5.5.3 Disconnecting the WiFi connection

To disconnect the WiFi connection, navigate in the setup menu to **Disconnecting the WiFi connection**. Then you can do the following:

- **Connect the set-top box to a different WiFi network:** Proceed as described in Section "Establishing a WiFi connection" on page 9.
- Establish the network connection using a network cable: Connect the network cable included in the package contents as described in Section "Cable connections" on page 7.

5.6 Software updates

Software updates are installed automatically. If a software update is already available when you first start using the product, you have to install the software update first. To do so, follow the instructions on the TV set.

6 Remote control

The remote control has an automatic power saving mode to increase the battery life. Power saving mode has ended when the green LED flashes twice in quick succession.

The remote control can be used in Bluetooth or infrared mode. You can also program in a TV set. This allows you to control the set-top box and your TV set with the remote control. To change the operating mode (Bluetooth or infrared), see Section "Changing the operating mode" on page 16.

6.1 Button functions



Figure 9: Button functions

(\mathbf{i}) The button functions and the range of functionality may differ.

(i) The functions of some remote control buttons depend on the respective function being performed and the screen in the user interface. Go to Help in the respective screen for more information.

1	On/off (standby)		Select date/time (TV guide/EPG)	
2	Number buttons	14	Negative content rating	
3	Open teletext	U	Reset channel sorting/list of	
4	Open search		favourites	
6	Show programme	Ð	Positive content rating	
6	Confirm input		Record programme/ delete recording	
	Show context menu	16	Delete search term	
7	Navigation buttons		Remove mobile device	
8	Open TV guide	D	Fast forward/reverse	
9	Show menu	13	Forward/reverse	
	Change source on set-top box	Ð	Mute	
0	Channel up (+) and down (-)	<u>_</u>	Volume up (+) and down (-)	
æ	Pause/continue playback (recorder/replay/video on demand)		Back	
W			Page up/down	
	End playback (recorder/replay/ video on demand) Current programme (TV guide)		Show quick guide	
12			Show programme details	
			Delete character	
	Open stream settings		Go to previous programme	
B	Turn screen off (radio)	25	Show help	
	Show list of favourites		· · ·	

6.2 Changing the operating mode

The remote control is in Bluetooth mode on delivery. To change the operating mode, proceed as follows:

1. Press and hold down the 7 and 9 buttons simultaneously for at least 3 seconds.

 \checkmark The green LED on the remote control is lit.

2. Enter the code you want (see Table 1).

 \checkmark The green LED on the remote control flashes twice in quick succession.

The selected operating mode is now active. You can change the operating mode in the same way at any time. For instructions to reset the remote control to factory defaults, see the section "Resetting the remote control" on page 20.

Operating mode	Description	Code
Bluetooth (default)	Controls the set-top box in Bluetooth mode. The remote control must be paired with the set-top box for this.	1
Infrared	Controls the set-top box in infrared mode.	2

Table 1: Operating modes

6.3 Programming the TV set

(i) The remote control may not be compatible with your TV set.

(i) Note the specifications for the respective programming type. If you deviate from them or do not press a button for 15 seconds, the programming process is cancelled. This is shown by the green LED flashing once.

The remote control has an integrated database with TV codes for numerous brands. Depending on the brand of your TV set, you can a program TV code in different ways:

- Manual programming: you need to enter the TV code manually.
- Brand code search: you can search for the desired TV code within a brand.
- Automatic code search: you can search the entire TV database for a suitable TV code.

6.3.1 Manual programming

For manual programming, you have to enter the corresponding TV code directly. Depending on the brand of your TV set, you may have to try several TV codes before you find the right one. A list of all supported devices is provided at **www.ocilion.com/gebrauchsanleitungen**. If you know the TV code for your TV set, this is the fastest programming method.

- 1. Switch on your TV set
- 2. Press and hold the 1 and 3 buttons at the same time for at least 3 seconds.

 ✓ The red LED is lit.
- 3. Enter the 3-digit code according to the TV code list.

 \checkmark If the TV code is valid, the red LED flashes twice in quick succession.

- 4. Press and hold the 26 button and then press 0.
 - \checkmark If the TV set is switched off, the TV code is correct.
 - ✓ If the TV set does not respond to the command, complete steps 2 through 4 using other codes from the TV code list until the TV set turns off.
- 5. Switch the TV set on again and repeat step 4 to try other buttons, checking whether they work correctly.

6.3.2 Brand code search

During a brand code search, you search the list of TV codes for a specific brand. The following table lists 10 TV brands. If the brand of TV set is not listed in the table, use a different type of code search.

- 1. Switch on your TV set
- 2. Press and hold down the v button and the matching code from Table 2 simultaneously for at least 3 seconds.

✓ The red LED is lit.

- 3. Press the \blacktriangleright button, and then the \circlearrowright button.
 - ✓ If the TV set is switched off, the TV code is correct. Switch the TV set back on and try out other buttons to see if they work correctly.
 - $\checkmark\,$ If the TV does not respond to the command, repeat step 3 until the TV is switched off or the other buttons work correctly.
 - \checkmark Pressing the Base button terminates programming without saving.
- 4. Press the **b**utton to confirm the TV code.
 - \checkmark The red LED flashes twice in quick succession.

Brand	Code
Samsung	1
LG	2
Sony	3
Philips	4
Panasonic	5

Table 2: Brand codes

Brand	Code
Loewe	6
Grundig	7
Sharp	8
Toshiba	9
JVC	0

6.3.3 Automatic code search

 ${ig(i)}$ The automatic code search can take several minutes. Therefore use this method only if none of the other methods worked.

The automatic code search, searches through the TV codes for ALL TV brands.

- 1. Switch on your TV set
- 2. Press and hold down the $\overline{\mathbf{w}}$ and $\overline{\mathbf{w}}$ buttons simultaneously for at least 3 seconds.

✓ The red LED is lit.

- 3. Press the 🕨 button, and then the 🙂 button.
 - ✓ If the TV set is switched off, the TV code is correct. Switch the TV set back on and try out other buttons to see if they work correctly.
 - \checkmark If the TV does not respond to the command, repeat step 3 until the TV is switched off or the other buttons work correctly.
 - \checkmark Pressing the ^{exc} button terminates programming without saving.
- 4 Press the **b** button to confirm the TV code
 - \checkmark The red LED flashes twice in guick succession.

6.4 Controlling the TV

 ${f i}$ Which buttons of the remote control are compatible with your TV set depends on the buttons of your TV set's original remote control.

After programming a valid code, you can control your TV set. Press and hold the button, and then press the desired button to control your TV set.

6.5 Unpairing the remote control (Bluetooth mode)

When you replace the remote control with a new one or reset the paired remote control to the factory settings, you have to unpair the remote control from the settop box.

- 1. In the user interface of the IPTV system, go to the **Settings > Remote control** screen or press the setup-button.
- 2. Follow the instructions to unpair the remote control.

 \checkmark The set-top box restarts.

 \checkmark The screen for pairing the remote control is shown.

3. Follow the instructions to pair the remote control.

6.6 Resetting the remote control

(i) When you reset the remote control to the factory settings, you also have to unpair the remote control from the set-top box (see Section "Unpairing the remote control (Bluetooth mode)" on page 20). Only then can you pair a remote control with the set-top box again (see Section "Pairing the remote control with the set-top box" on page 8).

To reset the remote control to the factory settings, proceed as follows:

1. Press and hold down the red and blue function buttons simultaneously for at least 5 seconds.

 \checkmark The green LED on the remote control flashes twice in quick succession.

- 2. Enter the digits **9999**.
 - ✓ If the green LED flashes twice in quick succession, the remote control has been reset to the factory settings.

The remote control is in Bluetooth mode. The Bluetooth connection to the set-top box and the programmed TV code (if any) have been erased.

7 Cleaning



Danger due to electrical voltage and resulting fire hazard

- → Disconnect the set-top box from the mains power supply before cleaning.
- → Clean with a dry, lint-free cloth.
- ➔ Only clean the surface of the devices.
- ➔ Never open the devices.
- ➔ Do not use cleaning agents that contain solvents.

8 Returning used devices

Applicable in the European Union and other European states with systems for the separate collection of recyclable materials.



Disposing of electronic equipment and batteries in household waste is not permitted. At the end of their life, return devices to the appropriate public collection centre or the point of sale. Details are governed by the respective national laws. The symbol on the product, the instructions for use or the packaging points out these provisions.

Reusing materials and recycling used devices makes an important contribution to protecting our environment.

To facilitate the disposal of used devices containing batteries, the batteries have to be removed before the devices are brought to a public collection centre.

9 Troubleshooting

Problem	Possible cause	Remedy	
The LED on the set-top box does not light up	No mains voltage or the set-top box is defective.	Check that the power supply unit and cable are properly connected. If the error persists, contact your provider.	
The set-top box cannot establish a WiFi connection	The MAC address of the set-top box is not allowed by the router.	Check the router and enable the MAC address of the set-top box.	
Support info 30 – 34 is shown for more than 3 minutes	Technical error while establishing the network connection.	Disconnect the set-top box from the mains network for about 5 minutes. Contact your provider if necessary.	
Support info 40 – 85	Technical error during a software update.	Disconnect the set-top box from the mains network for about 5 minutes. Contact your provider if necessary.	
Support info 65	No connection to the NTP server.	Check the network settings of the router. Contact your provider if necessary.	
The LED on the remote control permanently flashes green	The remote control has not been paired.	Pair the remote control (see Section "Pairing the remote control with the set-top box" on page 8)	
	The remote control is unable to establish a connection to the set-top box.	Check if the set-top box is connected to the mains network. If the problem persists, you have to pair the remote control again (see Section "Pairing the remote control with the set-top box" on page 8).	

Problem	Possible cause	Remedy
The set-top box does not respond to the remote control	The batteries are not correctly installed in the remote control.	Check if the batteries are installed correctly or whether they are drained.
	The batteries of the remote control are low or drained.	Go as close as possible to the set-top box and press any number buttons on the remote control. If the set-top box responds now, this means the batteries are low. Replace the batteries with new ones in this case.
	The remote control software has crashed.	Take out the batteries and put them back in after about 3 minutes.
	The Bluetooth receiver on the set-top box has crashed.	Disconnect the set-top box from the mains network for about 5 minutes. Contact your provider if necessary.
	The remote control was paired with another nearby device.	Reset the remote control to the factory settings (see Section "Resetting the remote control" on page 20). Deactivate pairing mode on any other nearby devices and repeat the pairing process (see Section "Pairing the remote control with the set-top box" on page 8).
No picture	No mains connection.	Check that the power supply unit and cable are properly connected.
	Defective cable connection.	Check cable connections to make sure they are tight.

Problem	Possible cause	Remedy
	Incorrect HDMI source.	Configure the HDMI source of the TV set on the set-top box.
Poor picture quality	Incompatible HDMI cable.	Only use the supplied high-speed HDMI® cable.
Jerky picture	The WiFi signal is too weak.	Go to setup and check the signal strength under WiFi status (see page 12).
	Limited bandwidth due to multiple users.	Use the network cable instead of WiFi.
The brand of your TV set is not in the code list or brand list		Perform the automatic code search (see Section "Automatic code search" on page 19).
The TV set does not respond even though the automatic code search was performed	The automatic code search performs the search on all codes. This may take up to 15 minutes.	Perform the automatic code search for at least 15 minutes.

Table 3: Troubleshooting

In case of further issues, contact your network operator.

10 Legal notes 10.1 Registered trademarks and notes on licences



Dolby, Dolby Audio and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation.

HDMI

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

Customer notes on MPEG LA licences are available on **www.ocilion.com/lizenzhinweise**

10.2 Open Source Software

The product also contains open source software. This software was developed by a third party and is subject to copyright. You are entitled to use the open source software in line with the applicable licence conditions.

For details of the licence conditions and further information, see **www.ocilion.com/opensource**

11 Declaration of conformity

The manufacturer hereby declares that the CE marking has been affixed to the devices in accordance with the essential requirements and other relevant provisions of the following directives:

- 2014/53/EU RED Directive
- 2009/125/EG Ecodesign Directive
- 2011/65/EU RoHS Directive

The full text of the EU Declaration of Conformity is available at **www.ocilion.com/ce**

12 Technical specifications

Item information	-		
Item no.	STB-P510E/020		
Colour	Black		
Weight	138 g		
Dimensions (W x H x D)	104 x 104 x 23 mm		
Environmental conditions	-		
Temperature	+5 - +40 °C		
Humidity	20 - 80 %		
Power / energy consumption	-		
Deep standby	0,2 W		
Normal operation	3,2 W		
Supported formats and codecs			
Audio codecs	ac3, wma2, mp3, aac, aiff, pcm, wav, mp2, aif		
Video codecs	xvid, m-jpeg, H.263, H.265, H.264, MPEG4, MPEG1, MPEG2, avc		
Video resolutions	1080p, 2160p, 720p, 576p, 1080i, 576i		
External connections			
 1 x Ethernet (RJ45) 	■ 1 x USB 3.0		
 1 x HDMI[®] output 	 1 x Micro SD card slot 		
Interfaces			
Bluetooth	5.0		
Infrared	36 KHz (RC-5:SAT2 / r-Step)		
Wifi	Wi-Fi 6E (2,4 / 5 / 6 GHz)		
Wifi security	WPA / WPA2 PSK / WPA3		
Copy protection	-		
DRM	Verimatrix Viewright		
HDMI®	HDCP 2.3		

Table 4: Technical specifications of the set-top box

Power supply				
Name of manufacturer	Ocilion IPTV Technologies GmbH Schärdinger Straße 35 4910 Ried im Innkreis / AUSTRIA			
Model identifier	STB-P490/0	STB-P490A/0		
Input voltage	100 - 240 V	100 - 240 V		
Input A/C current frequency	50 - 60 Hz	50 - 60 Hz		
Output voltage	12,0 V	12,0 V		
Output current	1,0 A	1,0 A		
Output power	12,0 W	12,0 W		
Average efficiency in operation (min)	83,3 %	83,7 %		
Efficiency at low load (10 %) (min)	73,3 %	78,1 %		
Power draw at zero load (max)	0,10 W	0,08 W		

Table 5: Technical specifications of the power supply

Item information		
Item no.	T4HU2020/41k / T4HU2020/41kA	
Colour	Black	
Environmental conditions		
Temperature	+5 - +40 °C	
Humidity	20 - 80 %	
Details of the radio standard		
Frequency band	2,402 - 2,480 GHz	
Max. transmitter power	1 mW	

Table 6: Technical specifications of the remote control

Version 2.7 Date 02-10-2023

Manufacturer: Ocilion IPTV Technologies GmbH Schärdinger Straße 35 • 4910 Ried im Innkreis / AUSTRIA Telephone: +43 7752 2144-0 • Internet: www.ocilion.com



In the course of product improvements, we reserve the right to make technical and visual changes to the devices described in these instructions for use. The current instructions for use are available on **www.ocilion.com/gebrauchsanleitungen**. Changes and printing errors excepted.